

	Location			
Align: Selections	Back of Curb Parallel to Chain	Back of Curb not Parallel to Chain	Circular manhole or intake	Tool Selection (See figure below)
<b>Tangent to Chain</b>	X			Click the <b>Station DP button</b> , choose the location in the <b>MicroStation</b> plan view.*
<b>Tangent to Element</b>	X	X		Click on the <b>Select MS Alignment Element</b> . In the <b>MicroStation</b> plan view click on the element to which the intake is to be tangent. Click again to accept the element. Click the <b>Station DP</b> button then choose the location in the <b>MicroStation</b> plan view.*
<b>Tangent on Element</b>	X	X		
<b>At point</b>			X	Click the <b>Station DP</b> button, choose the location in the <b>MicroStation</b> plan view.*
* the location can also be identified on the <b>Node Configuration - Location</b> window by keying-in the <i>Station:</i> or <i>Angle:</i> or checking the <i>Offset:</i> or <i>Mirror Node</i> box				